

Submittal Data Information

Roth DWT Waste Oil Fill Pan



Effective: September 2007

Supersedes:

Job: _____ Engineer: _____ Contractor: _____ Rep: _____

ITEM PART NO.	ITEM DESCRIPTION	MANUFACTURER
#2335000777	Waste Oil Fill Pan	Roth

Description

Waste Oil Fill Pan



The waste oil fill pan is used with the Roth double wall tank (DWT) to provide a convenient means to pour wasted motor oil into the DWT with a minimum of mess. The construction is all galvanized steel.

The fill pan features a closable and lockable lid for security. It also includes a removable screen for cleaning.

Installation

The fill pan is attached to the DWT by means of legs that rest on the top lip of the tank. The legs are drilled so that a self tapping screw or the supplied bolts and nuts can be used to secure the legs to the tank lip. The angle of the legs can be repositioned as needed for a good fit.

Waste Oil Pan Mounted



The underside of the pan is equipped with a male 2" NPT connector. The DWT female 2" NPT adapter can be screwed onto the fill pan connector, providing a positive connection to the fill port on the DWT.

Fill Pan Dimensions

Overall Width – 13 1/2"
 Overall Length – 16 1/8"
 Inside Width – 10 1/8"
 Inside Length – 14 1/4"
 Overall Height (Closed) – 9 5/8"
 Overall Height (Open) – 21 7/8"
 Weight – 18lb. 4oz.

Your Environment is Our Business.®

ROTH Industries, Inc, 268 Bellew Avenue South, Watertown, NY 13601
 ROTH Industries, Inc, Canada

Telephone: (315) 755-1011 Fax: (315) 755-1013
 Telephone: (800) 969-7684 Fax: (450) 464-7950

Visit our website at: www.roth-america.com

Copyright 20